



Environmental Health & Safety

Oklahoma State University



EHS CONTRACTOR MANUAL

Environmental Health and Safety | University Health Services Suite 002 | Stillwater, OK 74078 | (405) 744-7241 | www.ehs.okstate.edu

Reviewed and Revised May 2016

Status

Contact(s)	Implementation Date	Comments
Kim Southworth, EHS	May 2016	Manual updated

A. Introduction

The EHS Contractor Manual contains performance expectations applicable to all contractors and their personnel regarding environmental, health, and safety responsibilities while working at OSU. To ensure the protection of OSU's students, faculty, staff, visitors, and property, contractors are expected to provide a safe and secure workplace and operate in an environmentally sound manner. Strong Environmental Health and Safety (EHS) programs will prevent injuries, control losses, and minimize environmental impacts. We expect contractors to join us in providing a workplace free of uncontrolled hazards to people, the environment and our campuses.

All Construction, Service and Maintenance Contractors must comply with all federal, state and local laws, as well as OSU's EHS-related policies and procedures. The OSU requirements in this manual may be stricter than government regulations. This document is a summary of EHS performance expectations. It is not intended to replace or limit the requirements of government regulations or standard industry practice. It is the Contractor's obligation to meet applicable EHS requirements, whether or not they are addressed in this document.

OSU Contractor Safety Program does not directly manage the safety of contractors or their personnel. OSU will communicate known hazards. Contractors are expected to manage Environmental, Health, and Safety hazards, risks and programs for their employees and subcontractors. This manual has been published to communicate OSU's EHS philosophy and expectations to all Construction, Service and Maintenance Contractors that do business with the University.

Contractors are responsible for awareness and full compliance with all applicable rules, regulations, laws, and practices applicable to their work and their Subcontractor's Work that are prescribed by OSU and any federal, state or local government or agency that governs the safety and health of employees, students, faculty, and the general public as well as protection of the environment. These include, but are not limited to, regulations promulgated by the following federal and state agencies: OSHA, EPA, DOT, DOE, NRC and OKDOL.

Contractor work areas may be observed and inspected at any time to ensure compliance with this manual. OSU designated staff, including the OSU Project Representative, OSU EHS, and University Fire Marshal, may perform inspections. In addition, a neutral third party may be secured by OSU to perform these inspections. Any deficiencies noted during the inspection must be corrected immediately. Repeat or serious violations could result in disciplinary action and/or expulsion from OSU property.

B. General Requirements

Entrances and Exits

Contractors may use only those entrances and exits designated for the work area. OSU posts emergency exits with appropriate signs and often equips them with exit alarms to discourage unauthorized use. Contractors who need to disable door alarms shall obtain prior approval from the OSU Project Representative and University Fire Marshal. Exit doors shall not be blocked. In addition, doors to restricted areas may not be left unsecured or unmonitored.

Incident Reporting

In order to maintain a safe and secure work environment, Contractors shall report any incidents or observations that may affect the safety of their personnel, OSU employees and students.

Unsafe acts or behavior - Report unsafe behaviors and conditions immediately to the OSU Project Representative. Stop work if an imminent danger exists. Work must cease until the Contractor corrects the issue to the satisfaction of the OSU Project Representative.

Accidents, Injuries, Near-Miss - Within 24 hours of an accident or injury, Contractors shall report details of all such incidents to the OSU Project Representative and OSU EHS. The Contractor will document an accident investigation on all injuries other than first aid cases as defined by OSHA Record Keeping Guidelines.

Emergencies - Contractors are responsible for implementing their own system for accounting for employees during an emergency.

Security Issues - Notify the OSU Police Department at 405-744-6523, or 911 in the event of an emergency, to report any issue causing a security concern. This may include theft, threats or acts of violence, malfunctioning or disabled security devices and violations of security policies or procedures.

Prohibited Items

OSU prohibits alcoholic beverages, illegal drugs, firearms, ammunition and other weapons on its premises. OSU may refuse entry to any person possessing such items, or suspected of being under the influence of alcohol or drugs.

Individuals (or Contractor crews) found in the possession of alcohol and/or illegal substances will be immediately removed from the site. If alcohol and/or illegal substances are found on-site in a gang box, conex box, office, or vehicle, and the individual(s) responsible cannot be identified, the entire crew will be removed from the site. People "under the influence" of alcohol, illegal substances, or prescription drugs which are incorrectly used shall be removed from the site and suspended for a period of time as determined by the OSU Project Representative.

The presence of designated drugs in an employee's system or the manufacture, sale, distribution, purchase, possession, dispensing or use of such drugs while on OSU premises are strictly prohibited. The taking of prescription medication in the manner prescribed by a physician is an exception to this policy provided it does not impair a person's ability to perform his/her job.

Lethal and non-lethal weapons and firearms of all types, excluding knives and other tools used for construction activities, are prohibited from the OSU Campus at all times.

Protecting Building Occupants/Public Around Construction/Renovation Activities

Contractors conducting construction/renovation activities shall ensure that the health and safety of the OSU faculty, staff, students and visitors is not adversely affected. Whenever possible, exposure to physical and health hazards shall be minimized using engineering controls. Containment barriers, barricades, signs and localized exhaust ventilation shall be used. Building occupants and the general public must not be affected by emissions from construction/renovation activities. Contractors shall follow the contractor guidelines of ANSI A10.34 *"Protecting the Public on or Adjacent to Construction Sites."*

Since the hazards associated with construction and renovation often change as a project progresses, the Contractor must conduct periodic hazard assessments to anticipate and plan for these changes. In addition, activities such as cutting wallboard or other dust-generating operations have the potential to activate smoke detectors/building evacuation alarm systems.

Any changes in planned construction activities shall be brought to the attention of the OSU Project Representative so the appropriate notification can be made to all affected OSU staff and students.

C. EHS Contractor Program Management

EHS Program Enforcement

It is the responsibility of each Contractor to comply with this manual as well as all applicable federal, state, local, and OSU requirements. Violations will be brought to the attention of the personnel involved and the responsible supervisory personnel. Identified violations must be promptly addressed and corrected. Violations may result in work stoppage (at the Contractor's cost) and will result in progressive enforcement action that range from temporary to permanent expulsion of personnel from the site. If the violations are severe or repetitive, the Contractor may be prohibited from working for OSU. If a Contractor fails to correct a problem, OSU reserves the right to take corrective action and back-charge the cost of any corrective action to the Contractor. Contract language enables OSU to dismiss any individual, crew, or Contractor who fails to comply with the OSU safety and security rules and regulations.

Contractors may be required to take other corrective actions, such as conducting an incident review, stopping work, holding safety reviews for the entire crew or company, providing increased training of employees, etc. at the discretion of OSU.

Safety Inspections

Contractors are required to conduct and document safety inspections of their work areas and practices, and those of their subcontractors. Contractors shall immediately correct hazardous conditions noted. Contractors shall maintain records of these safety inspections and provide them to the OSU Project Representative upon request.

Safety Representative

The Contractor may be asked to assign a representative to monitor compliance with EHS requirements. The Contractor shall provide 24-hour, emergency contact numbers or list to the OSU Project Representative. The Contractor's Safety Representative may be an individual located off campus. However, for large projects or special hazards, OSU may require the Contractor to provide a dedicated Safety Representative, such as an OSHA-required "competent person." The OSU Project Representative and EHS will determine the need for an on-site Safety Representative.

Regulations require "competent persons" for situations, such as, crane operations, electrical safety, excavations, fall protection, and scaffolds. OSU expects (where applicable) Contractors to have trained competent persons within line of sight of such activities. OSU management will periodically audit projects requiring competent persons. If a qualified competent person is not available, work will be stopped.

Training

Contractors are fully responsible for the training of their employees assigned to work at OSU. When training is required by law or regulation (e.g., oil handling personnel, hazardous waste operations or asbestos workers), the Contractor shall ensure that only trained workers are assigned to work at OSU. In addition to meeting the regulatory requirements, it is OSU's expectation that all personnel shall be adequately trained in proper techniques to safely perform the job assigned to them.

D. Health & Safety Requirements

Blasting & Explosive Use

Prior to engaging in projects involving the use of blasting or explosives, the Contractor must submit a comprehensive Blasting Plan to the University Fire Marshal and OSU Project Representative for review and approval. The plan must include, but not be limited to, the following elements:

- Pre-Blast Surveys and Seismographic Locations
- Site Safety and Job Hazard Analysis
- OSU Notification Procedures
- Blasting Monitoring
- Sequence of Blasting
- Blasting Procedures
- Blasting Mats
- Blasting Security & Warning Whistles
- Explosives information—type, quantity, transportation, storage, etc.
- Blasting Personnel
- Blaster Qualifications
- Blast Vibration
- Blast Reports
- Typical Blast Design

It is the responsibility of the Contractor to determine if any special licenses and permits are required to perform blasting operations at the work site, and to obtain those licenses and permits as part of the project. Copies of all plans, permit applications, licenses and any approvals shall be provided to the OSU Project Representative prior to commencing work. Blasting operations shall comply with all federal, state and local regulations, including NFPA 495.

The Contractor shall ensure that explosive materials are stored in a manner consistent with applicable regulations and shall never store more than a one-day supply of explosives on an OSU work site. Any excess explosive material must be removed from campus immediately. Contractors shall account for all explosives at all times and report any missing explosives to the OSU Police Department and OSU Project Representative, as soon as the loss is discovered.

Only trained, qualified and authorized individuals may handle and use explosives. Contractors shall employ the use of signs, barricades, flags, audible and visual warning devices and any other means indicated to ensure the safety of the workers and the surrounding public.

Contractors must take precautions to prevent the accidental discharge of electric blasting caps from current induced by radio transmitters (pagers, cell phones, radios), radar, lighting, adjacent power lines, dust storms, or other sources of extraneous electricity. The Contractor shall indemnify OSU for fines, penalties or other legal exposures caused by blasting operations.

Chemicals, Hazardous Materials and HAZARD Communication

Chemicals and hazardous materials used at OSU shall be accompanied by a Safety Data Sheet (SDS).

Prior to use of the material(s), Contractors shall provide an SDS to the OSU Project Representative for distribution to affected University personnel. SDSs are required for various chemicals, solvents, paints, thinners etc., in the workplace.

Contractors and their employees shall comply with all regulatory requirements in the management of the chemicals and hazardous materials they use at OSU. Contractor personnel should be thoroughly familiar with the information contained in the SDS and shall use the materials safely. If the use of the material has the potential for exposure to OSU personnel (students, faculty, employees or residents) OSU EHS must be consulted before starting the job via the OSU Project Representative. The SDS must be forwarded to OSU EHS. OSU EHS is available to make recommendations to minimize occupant exposures to chemicals or hazardous materials. Contractors shall be aware that vapors and/or odors from chemicals can travel long distances. Every attempt shall be made to minimize or eliminate the potential for exposure.

Contractors shall provide secure and compliant storage, containers, and spill control for chemicals (including fuels and oils) stored on open ground or other areas lacking spill containment.

Contractors shall immediately report any oil or chemical spill or release to the Stillwater Fire Department by dialing 911, and also by notifying the OSU Project Representative. OSU may ask the Contractor to notify government agencies, if required by federal and state environmental laws governing spills and releases.

Contractors are fully responsible for responding to oil and/or hazardous material spills resulting from their actions or from their failure to provide adequate safeguards, including without limitation the full cost of the response and any associated clean-up. The OSU Project Representative will notify EHS of any spills or releases that the contractor reported to the Stillwater Fire Department and will consult with OSU EHS to ensure that any waste generated is properly removed and disposed. If the Contractor fails to perform any action required, OSU, at its option, may complete the action at the Contractor's expense. The Contractor shall indemnify OSU for fines, penalties or other legal exposures caused by the spill.

Contractors are responsible for managing their chemical containers according to federal, state, and local regulations. Contractors shall remove any remaining chemicals or hazardous material products within 24 hours of their completed use on a project, unless approval is received from the OSU Project Representative to leave the material on site.

Contractors that generate waste materials will comply with all regulatory and OSU requirements. Contractors may not discharge chemicals or wastewater to drains without the written approval of the OSU Project Representative.

Special precautions shall be observed prior to using any chemicals or hazardous materials in mechanical, electrical or air distribution rooms. The OSU Project Representative and OSU EHS must be notified prior to use of chemicals in these areas.

Space specific entry procedures should be reviewed in a pre-planning meeting. Permit space entry procedures must be conducted as outlined in the departmental SOPs and entry permit and must include a debriefing of personnel involved in the entry when the task has been concluded.

Combustion Engines Indoors

Contractors shall not operate combustion engines, such as those in vehicles, compressors, generators, welding machines and power tools, inside buildings unless they connect the exhaust to an approved venting system.

Do NOT refuel with the engine running. Contractors shall store fuel (gasoline, diesel and/or LPG) outside OSU buildings in approved and appropriately marked containers and compliant storage areas.

Compressed Gas Cylinders

Cylinders shall be properly secured and labeled to identify contents in accordance with OSHA's Hazard Communication Standard (1926.350, 1910.1200).

Workers shall close valves when cylinders are idle, empty or moved. Valve protection caps shall be in place when cylinders are moved or stored.

Contractors shall comply with OSHA requirements and consensus standards from the Compressed Gas Association on the separation of cylinders containing incompatible chemicals. Oxygen cylinders in storage shall be separated from fuel-gas cylinders or combustible materials (especially oil or grease), a minimum distance of 20 feet or by a noncombustible barrier at least 5 feet high having a fire-resistance rating of at least one-half hour. A cart with oxygen and fuel-gas cylinders is in storage when it is reasonably anticipated that gas will not be drawn from the cylinder within 24 hours (overnight hours included). At that point the storage requirements must be met.

Regulators, hoses and torch assemblies shall be in working order and checked for leaks prior to initial use or installation. If a leak develops, remove the cylinder to a safe location outside the building.

Compressed gas cylinders shall never be brought into confined spaces.

Confined Space Entry

Contractors who may need to enter a confined space at OSU as part of service delivery shall conduct entry under a Permit-Required Confined Space program in compliance with OSHA 29 CFR 1910.146. Permit-required confined spaces may include, but are not limited to, storage tanks, in-ground vaults, boilers, trenches, manholes, lift stations, and valve pits.

If during the course of work, the Contractor encounters a confined space that has not been previously identified by OSU, the Contractor must notify the OSU Project Representative so that the space can be assessed by the OSU Project Representative in consultation with OSU EHS.

Prior to conducting work in or around a Permit-required Confined Space, Contractors shall notify the OSU Project Representative. Upon this notification, OSU shall provide the Contractor with information relative to the known or anticipated hazards of the space. Upon completion of the confined space entry, the Contractor will notify the OSU Project Representative and provide information on any unexpected hazards that were encountered. **This sharing of information shall be made using the Permit-required Confined Space Contractor Notification Form in [Appendix 1](#) of this manual.**

Contractors are expected to comply with the OSHA Permit-required Confined Space Standard. Therefore, they are expected to:

1. Have a permit space entry program in place that meets the OSHA standard.
2. Ensure their employees are properly trained.
3. Have and use the equipment and resources available to ensure a safe entry, including atmospheric testing equipment, protective clothing, hard hats, respirators, life-lines, ventilation equipment and safety harnesses etc.
4. Provide for emergency rescue. The Contractor must arrange for the appropriate level of rescue services based on the potential for the types and complexity of the rescue that may be required. Documentation on the rescue procedure, authorized rescuers, training and equipment must be available on site prior to conducting confined space entries requiring rescue services.

Cranes and Hoists

The Contractor shall not use OSU-owned or leased crane or hoist equipment, unless contractually indemnified to do so or unless they have signed a separate indemnification authorizing them to do so.

Before lifting the first load of the day, the Contractor shall verify the hoist system will operate properly by conducting documented inspections. These inspection documents should be made available upon request of the OSU Project Representative.

Contractors shall not leave suspended loads unattended. When moving a suspended load, the operator shall assure personnel are clear of the path of transport. Workers will not stand or walk under suspended loads.

Crane operators and riggers shall be thoroughly trained and competent in the use of such equipment.

The Contractor shall provide a "competent person" (as required by OSHA) to oversee and/or perform lifting operations.

Contractors shall establish a restricted work area using barricades and other appropriate controls to minimize the hazards to personnel from swinging or falling objects. See the "SIGNS, SIGNALS AND BARRICADES" section of this document for details. The work area boundary must be created in response to the level of potential pedestrian traffic that could be expected to pass through. At a minimum, in light traffic areas, a boundary shall be set up with snow fencing on stanchions, posted with red "DANGER- Do Not Enter" tape and enough ground crew personnel to challenge any pedestrians who wish to pass through. If an unauthorized person enters the work zone, all work must stop. If the lifting work zone will be set up in high pedestrian traffic areas, then portable chain link fencing may be necessary to channel traffic around the work zone. As an option, performing the picks during early morning hours or weekends can preclude the use of chain link fencing in these areas, but snow fencing, danger tape and ground crew requirements remain.

Contractors shall ensure that all building exits that open into the work zone are monitored by ground crew personnel to prevent pedestrians from exiting into the work area. If building exits need to be blocked, permission to do so must first be obtained from the University Fire Marshal, as these exits may be necessary for fire egress.

Electrical Safety

Energized electrical equipment and services represent a significant hazard on every job site. OSHA's electrical standards (29 CFR 1926.400) address the long-held recognition that electricity poses a serious workplace hazard, exposing employees to such dangers as electric shock, electrocution, fires and explosions. OSHA's regulations related to electrical safety recognize two key hazard management tactics: elimination of the hazard through shut down and isolation (Lockout/Tagout 29 CFR 1910.147); or when live circuits must be maintained, the use of Energized Work Permits and protection from contact through the use of guarding, insulation, and protective equipment.

There are other considerations related to electrical systems that must not be overlooked. The National Electric Code (NEC) and NFPA 70E define design, proper installation and worker safety parameters associated with electrical systems maintenance and installation, as well as PPE that must be worn in potential arc-flash areas.

Not only must employee contact with electrical systems be avoided, fires and explosions due to overheating and arcing of electrical systems must be prevented as well. Some OSU facilities contain "rated" areas where "explosion-proof" or intrinsically safe lights, conduits, motors, controllers, and switches are used to prevent the ignition of flammable or explosive liquids and gases. Accidental use of non-rated equipment (such as cell phones, power tools, radios) in these areas could have catastrophic consequences.

The following is a partial list of items to consider when working with or near energized systems:

1. Contractors will comply with OSHA Subpart K Electrical regulations and the current editions of the National Electric Code and NFPA 70E.
2. Contractors must identify and document competent and qualified persons properly trained, licensed and protected.
3. Contractors shall comply with the OSHA "Lockout/Tagout" Standard (29 CFR 1910.147) when working with de-energized equipment or circuits. Contractors shall identify the switches that energize the affected circuits or equipment. Due to their ability to store residual electrical energy, medium and high voltage circuits shall be grounded on both sides of affected workers. Contact the OSU Project Representative for assistance in identifying the locations of energy isolating devices.
4. All permanent and temporary electrical work shall be done in accordance with National Electric Code, OSHA and other applicable standards.
5. Contractors installing electrical service will label circuit breakers and disconnect panels as to their purpose.
6. The responsible Contractor shall properly tag temporary feeder wiring at the source for identification purposes.
7. Exposed voltage in occupied areas shall be attended by a Contractor employee or be posted and barricaded by the Contractor within an enclosed radius safe area as recommended per NFPA 70E.
8. Electrical equipment inspection is to be done in accordance with the manufacturer's specifications, or on a quarterly basis at a minimum. Records of these inspections shall be made available upon request.

9. Frayed or cut electrical cords, or cords with damaged plugs or missing ground plugs shall be immediately removed from service, rendered unusable, and removed from the site.
10. The OSU Project Representative reserves the right to confiscate and destroy any defective tool or cord immediately upon discovery if the defective tool or cord has not been rendered unusable.
11. Electrical connections shall be coordinated with an OSU electrician.
12. Electrical tie-ins shall be conducted only on de-energized (locked out and tagged out) systems.
13. Unauthorized, live tie-ins to electrical services are prohibited and will result in the immediate and permanent exclusion of the worker from all OSU facilities.
14. After a Contractor performs repairs, maintenance or installations, and before OSU qualified employees attempt to re-energize the electrical equipment, verification shall be performed to ensure that the electrical equipment components are operationally intact and that no electrical hazard exists upon re-energization. This verification can be performed by qualified persons from the OSU Facilities Electric Shop or a qualified third party, at the discretion of the OSU Facilities Electric Shop supervisor.

Emergency Equipment

Contractors may not block or obstruct access to emergency equipment, such as self-contained breathing apparatus, first aid kits, eyewash stations, safety showers, fire extinguishing equipment, fire hydrants, transformers and emergency generators. Contractors may not relocate, obstruct or disable emergency equipment without prior permission of the OSU Project Representative.

Excavation and Trenching

Prior to excavating, trenching, or otherwise penetrating the ground (including driving tent stakes or sign posts deeper than 12 inches), Contractor shall be responsible for utility marking, signage and barricades, shoring, and following applicable confined space entry procedures. No excavation activity may take place until an OSU permit has been obtained. No excavation operation activity may take place outside the dates of an issued permit. Excavators may not “piggy back” off other excavation permits.

The excavation permit start date begins with the date/time of the original OKIE request and is in effect for 10 working day. The Contractor receives the permit electronically at the email address included in the OKIE Locate request. The permit must be present on the job site for the duration of the operation.

If work is going to extend beyond the permit expiration date, to ensure that the work may continue without interruption the Contractor must submit a new OKEI Locate request a minimum of 48 hours prior to the expiration of the original permit and acquire an updated permit before work can continue.

The Contractor’s receipt of the Permit acknowledges completion of the OSU locates and acceptance of responsibility for adhering to, at all times during the Operation, OSU’s Trenching and Shoring Procedures: <http://ehs.okstate.edu/manuals/trench.htm> and the State’s safety guidelines as defined by OK §142.1 – Oklahoma Underground Facilities Damage Prevention Act. <http://www.callokie.com/how-it-works/the-law/>

As of August 27, 2015 under Title 165, Chapter 20, Subchapter 17 of OK§142.1 – it is now required that: “An excavator shall immediately call the local 911 emergency telephone number and report any incident

that results in an unintentional and uncontrolled release of flammable, toxic or corrosive gas or liquid from a pipeline or pipeline system.” In the event any utility lines are hit during the excavation all activities must cease and OSU emergency contacts be notified.

The Contractor is responsible for restoring the site back to its original condition once the excavation operation is completed. The Contractor assumes financial responsibility for the repair of any damage caused by the excavator to line or facilities if the steps given in the excavation permit procedures are not followed.

The Contractor shall comply with the OSHA Excavation Standards (29 CFR 1926.650) and other regulatory requirements associated with the work. If the Contractor encounters any suspect material (i.e., discolored soil, pipe not on OSU's excavation package drawings, asbestos, etc.), the Contractor shall stop immediately and contact his OSU Project Representative. If the soil is contaminated, OSU EHS will arrange for its proper removal and disposal.

The Contractor shall place conspicuous warning signage and barricades or fencing on all sides of a trench or excavation to prevent pedestrians from crossing the opening.

The Contractor shall provide a “competent person” as required by OSHA Excavation Standards (29 CFR 1926.650) to inspect the excavation area and protective systems. Excavations greater than 20 feet deep require excavation protection plans that are designed and executed under the supervision of a professional engineer licensed in the State of Oklahoma. This would apply to sloping, use of trench shields (trench boxes) and shoring systems.

Contractor shall utilize the appropriate protective system (sloping, trench shields (trench boxes) or shoring per 29 CFR 1926.650 for all excavations five feet or greater in depth and/or as site conditions require. Excavation and trench work at shallower depths may require protection when the workers' chest height is less than the depth of the excavation or trench.

Ramps shall be constructed in accordance with 29 CFR 1926.651 by a competent person, as defined by the OSHA Excavation Standard.

Eyewashes and Safety Showers

Contractors are responsible for supplying eyewash and safety showers for their employees while performing work on the OSU campus. They will ensure these units are in full operational compliance for use during an emergency.

If no permanent unit is available, then a temporary unit shall be provided and utilized by the Contractor. The Contractor is responsible for assessing the adequacy of all units to be used, whether permanent or temporary, and to ensure that they are in full operations compliance.

Fall Protection

Contractors shall provide fall protection for its employees, as required by 29 CFR 1926.500. Fall protection is required in areas where the fall hazard is 6 feet or greater from the worker's foot-level, or where the individual is working over dangerous equipment.

Contractors shall provide adequate protection where there is a potential for endangering persons below. Contractors shall isolate such work areas to protect persons from falling objects. In addition, the Contractor shall barricade and monitor an area of twenty-five (25) feet minimum radius from such work

to prevent unauthorized personnel from entering the hazard area. If the Contractor cannot establish this secure area due to operational constraints, then the work must be scheduled during off-shift hours.

Users of fall protection equipment shall perform a documented inspection of their equipment before each use. Workers shall raise and lower tools and equipment to overhead work areas through the use of aerial work platforms or ropes and tethers. Throwing or dropping tools and equipment is prohibited.

Floor Openings: Working within six feet of a floor opening (skylight, hole, open hatch, etc.) requires appropriate fall protection. Floor openings (holes) shall be protected with a fixed cover, using materials of sufficient strength to support any imposed load or to equal the design floor loading capacity, or shall be guarded by a standard OSHA-compliant fixed railing system with toe boards on all exposed sides except at entrances to stairways.

When floor openings are protected with covers, the cover shall be clearly marked: **“Danger- Hole - Do Not Remove.”** To minimize the exposure time, openings in floors shall not be cut until the last practical moment, and then only by the Contractor who will utilize or fill this floor penetration. For example, the concrete for a floor penetration in an elevated slab may be boxed out, but the decking must be left in place to be cut by the mechanical Contractor who will utilize the penetration. Precut holes in slabs and metal decking are discouraged. The Contractor that cuts the floor opening shall be responsible to maintain it, unless “ownership” is transferred to others in the contract documents.

Ladders: The following guidelines apply to all OSU facilities per OSHA 29 CFR 1926.1053

1. All ladders must be in good condition and free of any broken or defective parts.
2. Metal or conductive ladders are prohibited from use for electrical work or within 10 feet of overhead power lines at OSU worksites.
3. Any ladders with broken or split rails, rungs, steps, or any defective parts must be removed from OSU property.
4. Workers shall not place ladders in door swing areas unless the door is locked or otherwise blocked from striking the ladder. Blocking exit doors may require permission from the University Fire Marshal.
5. Ladders must extend a minimum of (3) three feet beyond the landing surface and be securely tied to prevent any movement. When used against beams, pipes, or similar supports, workers shall secure ladders to prevent shifting, slipping, or being knocked over.

Roof Work: Working on a roof will require appropriate fall protection (railings or warning lines with safety monitors or personal fall protection) in accordance with OSHA Standards.

Contractors shall not work on roofs without prior approval from the OSU Project Representative. Access to the roof will be controlled. Only authorized persons designated by the Contractor shall be granted access. Contractor must obtain other appropriate permits, as needed (e.g., Hot Work, Confined Space Entry, etc.), before working on roofs.

Fire Protection Impairments

Contractors shall take precautions to prevent damage to fire protection systems. Report damage immediately to the OSU Project Representative.

Except in emergency conditions, Contractors may not operate any fire protection valve/fire hydrant without prior approval of the OSU Project Representative and University Fire Marshal.

Contractors who need to disable a fire protection system shall contact the OSU Project Representative and the University Fire Marshal. Notify the OSU Project Representative of any planned fire protection impairment at least twenty-four (24) hours in advance to obtain an approval to shutdown. This applies to sprinklers, fire mains, fire pumps, and fire alarm system components.

During fire protection equipment impairments, all operations that present a fire hazard will be suspended. These would include all types of hot work. Fire protection systems should be restored as soon as possible by the end of the workday. Fire watch personnel may be required during fire system impairments.

Contractors shall not suspend materials or equipment on sprinkler pipes, valves or supports.

Fire Safety

Contractors should be familiar with the location of fire alarm activation devices (pull stations), portable fire extinguishers and at least two exit routes from the work area. Contractors shall not obstruct access to exits, exit routes or fire equipment or prop open stairwell doors.

All fires shall be reported by activating the nearest fire alarm station, followed by dialing 911.

Contractors shall be trained in the proper use of portable fire extinguishers if conducting fire watch duties. Contractor-supplied fire extinguishers shall be clearly marked and have current inspection. Contractors shall provide their own portable fire extinguishers for any hot work unless other arrangements have been made with the OSU Project Representative.

Flammable and combustible liquids are easily ignited and thus shall meet all the labeling, use, storage and disposal requirements outlined in the Chemicals and Hazardous Materials section in this document.

Contractors performing welding, torch cutting, soldering, grinding, using high temperature heat gun and other forms of "Hot Work" shall adhere to the special requirements listed in the Hot Work section of this document. Hot Work shall not be conducted during times when sprinkler systems have been impaired.

Provide a fire extinguisher as prescribed by University Fire Marshal in the construction areas, along with evacuation plans and Air Horns for emergency signals. The use of an air horn and evacuation plans should be described within the Contractor's Site Specific Health and Safety Plan.

First Aid and Medical Services

Contractors are responsible for ensuring that first aid and medical services are available for their employees and for reporting and recording injuries, as required by OSHA. Dial 911 to summon emergency assistance.

Hot Work

OSU utilizes and enforces the use of a Hot Work permit system to help minimize the risk associated with Hot Work. We encourage Contractors to provide suggestions/alternative methods on ways to avoid Hot Work. For instance, can bolted flanges be used? Can the welding be conducted outside? If Hot Work will be performed, it is OSU's expectation that Contractors document a job-specific hazard assessment. All flammable and combustible materials shall be removed from the area. The assessment also includes

evaluating other work in the vicinity that has the potential to create a hazard. The Contractor shall meet or exceed all regulations and industry standards when conducting Hot Work.

Contractors shall contact the University Fire Marshal to obtain a Hot Work Permit for any temporary operation involving open flame or which produces sparks. This includes, but is not limited to welding, cutting, grinding, brazing, and torch-applied roofing. The Hot Work Permit should be valid for only one job on one shift, unless other arrangements have been agreed upon.

Fire protection equipment and protective materials (fire blankets, portable exhaust ventilation etc.) shall be at the Hot Work site before the work begins. Oxy-acetylene torches shall have flashback preventers on both gas lines at the torch handle.

A designated fire watch may be required during Hot Work. The Contractor must provide trained personnel for this duty or may be required to hire a fire fighter detail for this purpose. If the fire watch observes unsafe conditions during the Hot Work operation, he/she shall stop the work until the hazard is eliminated.

The Contractor will verify Hot Work equipment is in proper working order and in a fire safe condition.

As the Hot Work Authorizer, the OSU Project Representative or designee may choose to inspect the Contractor's equipment before issuing the permit and may request the removal of unsafe equipment from the site.

Contractors shall use non-combustible or flameproof shields to protect nearby personnel from direct rays of welding arcs (asbestos blankets are prohibited).

Maintenance of Site

Each Contractor and all his employees are responsible for maintaining high standards of cleanliness and orderliness; anything less is unacceptable.

Housekeeping must be addressed on a continuous basis. Sloppy work practices will not be tolerated. In occupied buildings the work area shall also be mopped daily. Hazardous, flammable, trash, and/or excess waste material is to be removed from the work area daily.

The second aspect of housekeeping is maintaining construction materials in a neat, consolidated, and organized manner. Deliveries shall be sequenced so that only one week's worth of materials at most are on site at any given time, unless the Contractor has been given a specific lay down area in the contract documents for his use. Unused or excess/scrap materials shall be promptly removed from the site.

1. Temporary cords or hoses shall be supported at least six feet above the floor when routed across aisles. If this is not possible, cords and hoses shall be secured to the floor and protected from damage to eliminate trip hazards. The area shall be properly marked with appropriate warning signs or traffic cones to alert pedestrian traffic.
2. Workers shall place waste materials in proper containers. The Contractor will keep work areas clear of form and scrap lumber and other debris. Contractors will remove all waste materials and debris daily.
3. Contractors will place equipment and materials so as not to block exits, aisles, doors, stairs, ladder ways, emergency equipment or electrical panels.

4. Workers will remove nails and other sharp objects protruding from surfaces and will sweep up loose nails and screws.
5. Contractors may not store tools and equipment above work areas. Workers shall not leave materials in plenum spaces such as air handling rooms.

Lockout/Tagout

The Contractor will assure proper isolation and control of hazardous energy on affected equipment and machinery. Contractors will comply with the OSHA "Lock-Out/Tagout" Standard (1910.147) including training and equipping workers. Contractors are expected to maintain a written program and work cooperatively with OSU personnel for multiple lockouts.

Lockout/Tagout procedures must be exchanged and coordination of procedures must be discussed between the Contractor and OSU during a pre-job meeting. All concerned University employees must be effectively informed of the restrictions and prohibitions associated with the Contractor's Lockout/Tagout procedures. See also the Electrical Safety section of this document.

Noise

Contractors are required to comply with OSHA's Noise Standard, 29 CFR 1910.95. Contractors will be asked to cease work activities when noise levels to OSU employees or students can be expected to meet or exceed OSHA's Action Level of 85 dBA (8-hour TWA). Activities can resume when engineering or work practice controls reduce the level of noise below OSHA requirements. Should this not be feasible, work must be scheduled for a time when OSU employees, students and town residents are not impacted.

Additional project-specific noise reduction measures or restrictions may also be required to minimize disruption to teaching and learning activities.

Personal Protective Equipment

The Contractor shall provide workers with personal protective equipment (PPE) such as safety glasses, respirators, hard hats, gloves, and safety shoes when performing certain activities or when working in designated areas. Contractors shall perform workplace hazard assessments, as required by OSHA 29 CFR 1926.95, and provide required PPE accordingly. The OSU Project Representative will notify the Contractor when specific PPE is required for entering or working in a designated area at OSU. The Contractor shall ensure PPE is available, maintained, and used appropriately. The OSU Project Representative reserves the right to stop work if PPE deficiencies are noted.

Contractors must control their work zones and effectively communicate the hazards of the work zone and required personal protective equipment to all personnel requiring access to those work zones.

Contractors shall wear proper footwear and appropriate apparel and PPE when working at OSU. Sandals, open-toed shoes, shorts, and sleeveless shirts are prohibited at OSU construction work sites. Professional appearance is required. Muscle shirts, tank tops, or tee shirts with inappropriate graphics or slogans are prohibited.

Mobile Equipment/Work Platforms

Unless permitted by the OSU Project Representative, and supported by appropriate indemnification in the contract language, Contractors shall not use OSU-owned or leased aerial work platforms.

Contractors shall ensure that only trained and authorized personnel operate mobile equipment, such as extendable boom lifts, scissors-type lifts, and cranes. The Contractor shall provide trained personnel to assist the operator in clearing building fixtures or other obstructions when raising, lowering or advancing the equipment.

Contractors shall conduct a documented inspection of equipment prior to each day's use to assure it is in safe operating condition. Workers shall replace or repair defective equipment before bringing it on site.

For outdoor projects, workers may not operate cranes, aerial platforms, power shovels, or similar equipment within fifty (50) feet of overhead utilities without prior approval from the OSU Project Representative.

Only documented, trained and authorized personnel shall be allowed to operate Aerial Lifts per 29 CFR 1926.453. Aerial lifts (boom lifts) shall only be used for lifting personnel and their tools and must not be used as material hoists. The manufacturer's load limitations and operating requirements must be complied with. Personnel working in aerial lifts must be tied off to anchorages specifically designed for that purpose (railings do not meet fall protection anchorage requirements). Aerial lifts that are not equipped with such anchorages shall not be used. Work shall only be accomplished from the floors of the baskets and must not involve climbing on basket railings, ladders, or other elevating platforms. OSHA defined Frequent and Periodic inspections will be performed in accordance with manufacturer's recommendations. Copies of these inspection reports shall be kept on site. Belting off to an adjacent pole, structure or equipment while working from an aerial lift shall not be permitted.

If the work area is not included in a chain-link fenced area, contractors shall establish a restricted work area using barricades and other appropriate controls to minimize the hazards to personnel from falling objects or lift movements. See the "SIGNS, SIGNALS AND BARRICADES" section of this document for details. The work area boundary must be created in response to the level of potential pedestrian traffic that could be expected to pass through. At a minimum, in light traffic areas, a boundary shall be set up with snow fencing on stanchions, posted with red "DANGER- Do Not Enter" tape and enough ground crew personnel to challenge any pedestrians who wish to pass through. If an unauthorized person enters the work zone, all work must stop. If the lifting work zone will be set up in high pedestrian traffic areas, then portable chain link fencing may be necessary to channel traffic around the work zone. As an option, performing aerial work during early morning hours or weekends can preclude the use of chain link fencing in these areas, but snow fencing with danger tape and ground crew requirements remain.

Contractors shall ensure that all building exits that open into the work zone are monitored by ground crew personnel to prevent pedestrians from exiting into the work area. If building exits need to be blocked, permission to do so must first be obtained from the University Fire Marshal, as these exits may be necessary for fire egress.

Respiratory Protection

OSU expects each Contractor and its subcontractors to manage their own Respiratory Protection Program. The Contractor and its subcontractors shall comply with the respiratory protection requirements of OSHA 29 CFR 1926.103.

Respiratory protection requirements for specific jobs shall be documented in the Contractor's Standard Operating Procedures and the Contractor's Written Respirator Program.

Scaffolds

All scaffolding, staging, and work platforms must satisfy the applicable OSHA regulations (29 CFR 1926.450) and manufacturer's erection requirements. The use of site built staging or scaffolding is not allowed unless prior approval is obtained from the OSU Project Representative and the Contractor Safety Coordinator. The proper use of scaffolding requires that:

1. The scaffold be erected and inspected by a trained, competent person. OSU expects scaffold erectors and users to comply with regulations and standard industry practices per 29 CFR 1926.450 - 452. Contractors shall train scaffold erectors and users in safe work practices and procedures.
2. Scaffold erectors hired by the Contractor shall work under the supervision of a "competent person" as defined by OSHA Scaffolding Standards. The "competent person" shall be within sight of the scaffold erecting activity.
3. Compliant scaffolding will bear a green inspection tag, signed and dated by the Contractor's competent person each shift prior to use. If the green tag is not present, or it is not signed and dated, or a red tag is affixed, the elevated work platform shall be considered unsafe for use.

Signs, Signals and Barricades

At the entrance to the construction site or locations the following signage must be posted: "Construction Area," "Restricted Area," "Hard Hats, Safety Glasses, and Work Boots Required."

When Lasers are being used "Laser in Use" Signs shall be posted.

Parking areas shall be conspicuously marked "Parking for Construction Only" or "No Parking."

In locations where construction is occurring within an active building, work areas shall be barricaded to restrict and eliminate potential access and exposures to the public.

Guardrails, jersey barriers, snow fence, portable chain link fencing, etc. may be used to delineate and secure work zones based on the potential exposure and traffic at the locations. Delineation of work zones, either by guard rails, jersey barriers, snow fence, chain link fencing, etc., must also warn against any potential danger or immediate danger within, and inform persons as to the proper action required (e.g., **CAUTION - Do Not Enter** or **DANGER - Do Not Enter**).

Specific Regulated Materials of Concern

Asbestos

Asbestos-Containing Materials (ACM) and Presumed Asbestos-Containing Materials (PACM) exist in most University buildings. Prior to **any** renovation or demolition activities, including installations or repair work, an asbestos inspection by a licensed and certified asbestos inspector must be conducted. All asbestos materials that could be disturbed during work activities must be properly removed, in accordance with federal and state regulations, prior to work commencing. Contact the OSU Project Representative for information about the location of ACM/PACM, inspection data, or procedure for

sampling. Written documentation of asbestos sampling results must be maintained at the worksite for use by affected employees.

Contractors shall not disturb asbestos-containing materials in OSU facilities, unless authorized and hired to do so. In order to disturb or handle asbestos, Contractors and their employees must have the applicable training, licenses, or any other qualifications necessary to perform such work safely and in accordance with Federal, State and Local regulations.

Contractors are always responsible for ensuring that any work that requires a specific license (e.g. refrigeration systems repair, asbestos/PCB abatement and removal, pesticide application, etc.) is only performed by individuals who are appropriately registered and/or licensed.

All Contractors must comply with OSHA 29 CFR 1926.1101 training requirements for their employees who may contact, but not disturb, ACM and PACM. This is considered Class IV work and requires, at a minimum, 2 hours of asbestos awareness training annually.

All Contractors must comply with OSHA 29 CFR 1926.1101 employee exposure requirements and engineering and work practice controls for materials that contain <1% detectable levels of asbestos, and are thus not identified as an ACM, nor regulated by EPA.

Should suspect ACM or PACM be found during work activities, the Contractor will stop all work immediately and contact the OSU Project Representative. No work shall be attempted that could result in a release of asbestos to the environment.

In the event of an asbestos emergency (release to the environment), isolate and secure the area. Immediately contact the OSU Project Representative and OSU EHS during normal business hours. After hours or on weekends, contact the Facilities Management Action Desk (405-744-7154) and identify the nature and extent of the asbestos emergency.

No products containing asbestos shall be used, applied or installed during renovations, repairs, or new construction activities. Contractors are required to check new products to ensure they do not contain one of the identified asbestos minerals.

Lead Based Paint and Lead Containing Paint

Lead-based paint is identified by EPA, HUD, and the CT DPH, as paint containing more than 1.0 mg/cm² by XRF testing or 0.5% by weight by laboratory analysis

Contractors conducting work in pre-1978 residences and child-occupied locations must be in compliance with EPA's Renovation, Repair, and Painting Rule that became effective April 22, 2010. Evidence of certification must be provided to the UConn Project Representative. In addition, proper notification to tenants and occupants in these locations is necessary. Coordinate this notification with the OSU Project Representative.

OSHA considers all paint, even post-1978 residential paint as *lead-containing* when any amount of lead is present in the paint, even if found below the aforementioned levels as identified by XRF and laboratory analysis. If any identifiable amount of lead is present in the paint, the concern is the activity to the painted surface that could cause lead to become airborne in the employee's breathing zone. Exposure levels for lead in the construction industry are regulated by 29 CFR 1926.62. Many construction activities, such as hand scraping and sanding, light demolition, grinding, welding, cutting and burning have been shown to expose workers to airborne levels of lead that exceed OSHA's Permissible Exposure Limit (PEL). Contractors must follow OSHA regulations when **any** painted surfaces can be impacted.

In commercial and industrial buildings, only compliance in accordance with the OSHA Lead in Construction standard is necessary. Lead abatement professionals and Certified Renovators are only necessary when abatement or renovation and painting activities are conducted in pre-1978 residential and child-occupied locations.

While lead test data may exist for some OSU buildings, **Contractors must use documented lead-safe work practices in all University buildings**, in accordance with OSHA 29 CFR 1926.62. Depending on the construction activities (grinding, sanding, etc.), a paint identified as not lead-based ($<1.0 \text{ mg/cm}^2$) has the potential for creating an airborne exposure to workers which may exceed the OSHA PEL. Contact the OSU Project Representative to review test data as necessary.

All paint chip debris/waste must be collected and a hazard determination must be performed prior to disposal. All waste must be disposed of in accordance with Federal EPA Regulations. Contact OSU EHS for more details.

Contractors are always responsible for ensuring that any work that requires a specific license or certification (e.g. refrigeration systems repair, asbestos/PCB abatement and removal, pesticide application, etc.) is only performed by individuals who are appropriately certified, registered and/or licensed.

Contractors are prohibited from conducting the following activities: dry scraping or dry sanding of paint (regardless of the year applied); torch burning/welding on painted surfaces; using heat guns set above 700°F; using non-shrouded and non-HEPA filtered powered sanders, or grinders.

PCBs in Caulk

The EPA has recognized that caulk containing PCBs was used in buildings, particularly from the 1950s through the 1970s (<http://www.epa.gov/pcbsincaulk/>). Caulk is a flexible material used to seal gaps to make windows, masonry and joints in buildings and other structures watertight or airtight and some caulks were formulated with PCB for greater flexibility. PCBs were domestically manufactured from 1929 until their manufacture was banned in 1979 by EPA. In light of this, the following steps should be incorporated prior to any renovation or demolition project:

1. If it is believed that the caulk in the building was manufactured before 1979, when PCBs were banned by EPA, and the planned renovation activities will impact that material, then the material should not be disturbed by the Contractor until reviewed by the OSU Project Representative and a PCB remedial approach is developed.
2. Depending on the size and scope of the renovation impact, the suspect caulks may be either presumed to contain PCB, and managed/handled as such, or the OSU Project Representative may have sampling of the materials performed to determine PCB content. Contractor shall not perform sampling of any building materials for PCB content unless specifically authorized by the OSU Project Representative to do so.
3. Contractors must not disturb any known or presumed PCB-containing materials unless specifically authorized or hired to do so. In order to proceed with work involving handling PCBs, Contractors must be adequately trained and qualified in accordance with all applicable Federal, State, and local requirements, including proper OSHA training.
4. When PCB-containing caulk (confirmed or presumed) and associated impacted materials (substrate/soil) are removed and disposed of, it should be done utilizing engineering controls and

work practices which prevent contamination of surrounding materials/spaces and with the use of proper worker personal protective equipment (PPE).

5. EPA has developed Fact Sheets for Contractors for the safe handling of PCBs in caulk during renovations (<http://www.epa.gov/pcbsincaulk/caulkcontractors.htm>).
6. The Contractor must remove and dispose of any presumed or known PCB containing or contaminated materials per Federal regulations/statutes (e.g. EPA 40 CFR 761) and any project specific specifications/remedial plans.

Tools and Equipment

In general, Contractors shall provide their own tools, equipment and secure storage for valuable tools.

Contractors may not use tools owned by OSU unless authorized by the OSU Project Representative.

Contractors shall inspect and maintain tools in safe condition using them only for jobs in which they are intended per 29 CFR 1926.300.

Contractors shall use non-sparking tools in areas where flammable liquids or gases are stored or dispensed.

As indicated previously, portable electrical power tools, hand tools, machinery and equipment shall be approved by the appropriate agency, double insulated or have an approved grounding system. Ground Fault Circuit Interrupters (GFCI) shall be used in wet areas.

When using pneumatic tools, the Contractor shall disconnect hoses from air supply when not in use.

Vapor and Particulate Emissions / Occupied Spaces

Contractors conducting painting operations or other activities that create vapor or particulate-producing activities (sealing, grinding, sanding, welding, spraying, stripping, chemical etching, adhesive application, roofing, sweeping, etc.) must take into account the location of their activities, and the impact to OSU Staff, Faculty and Students, other contractors, active research or academic efforts. Emissions from the above-described activities have the potential to adversely affect indoor air quality and interfere with active learning.

Contractors using vapor emitting products or conducting particulate producing activities must prepare an air quality control plan that will prevent any negative impact to building occupant air quality. Contractors should be prepared to provide air monitoring equipment, ventilation equipment, and engineering controls to document and maintain acceptable indoor air quality. Materials of particular concern include products that emit high volatile organic compounds (for example, solvents), certain glycol ethers that are considered reproductive hazards, epoxy based products, byproducts of combustion, and isocyanates. Also to be considered is the location of air intakes when operating power equipment outside of occupied buildings.

In the event that suitable indoor air quality cannot be achieved, Contractors should be prepared to schedule activities outside of normal working hours, and protect their employees with an OSHA compliant respiratory protection program.

Welding Emissions

Contractor shall erect appropriate shields to prevent accidental exposure to welding emissions to students, faculty, staff and other contractors. If welding is occurring in an occupied building, the Contractor must supply a “smog hog” type filtering unit to remove welding smoke, fumes and /or vapors. An air quality control plan shall be submitted to the OSU Project Representative to address steps taken to monitor and control welding emissions.

E. Environmental Requirements

Air Pollution Control

Contractors must abide by good management practices to ensure that their daily activities do not adversely impact the air quality. These shall include, but not be limited to:

1. Contractors shall retain fuel slips for construction vehicles/equipment that are refueled on site. OSU requires that liquid fuels including “biofuels” consumed on-site shall not exceed the sulfur content of motor vehicle diesel fuel as defined in RCSA §22a-174-42” This includes all #2 oil and diesel burning equipment such as temporary boilers and heaters
2. No open burning is allowed on the OSU Campus.
3. Vehicles shall NOT be operated near building fresh air intakes, and shall be equipped with exhaust scrubbers to minimize impact to indoor air quality.

Equipment shall not be allowed to idle for excessive periods of time when not in use. Connecticut law prohibits vehicles of all kinds from unnecessary idling for more than 3 minutes. Provisions are made for weather extremes, certain service vehicles and health-related conditions. R.C.S.A. 22a-174-18. This regulation applies to ALL vehicles in Connecticut. Solvent or other noxious emissions shall be evaluated as part of the work planning process to determine engineering control requirements prior to field implementation of the scope of work. *Regulations of Connecticut State Agencies* restrict and/or defines the use of certain materials such as adhesives, sealants, and other VOC containing substances used in the State of Connecticut. Contractor should refer to Regulations of Connecticut State Agencies Section 22a-174 including Section 22a-174-44 Adhesives and Sealants.

Environmental Permits and Licenses

Contractors and other service providers may be asked to work with or on behalf of OSU Project Representatives to secure environmental permits. In some cases, the Contractor may submit the permit application. Contractors are responsible for following the requirements in the environmental permits. Project permits shall be on file with the project documents and shall be made available upon request.

Under no circumstances shall a contractor use a material in an application that is banned under the Toxic Substances Control Act (40 CFR 700-799).

Waste Management

Hazardous Waste

Contractors are fully responsible for all hazardous wastes that they generate while at OSU. Hazardous waste may be generated from construction and renovation activities and a variety of other contractor's activities at OSU.

Common hazardous wastes generated at OSU include:

1. Waste solvents and solvent soaked rags;
2. Waste oils and lubricants generated by a variety of operations including motor vehicles, elevators, plant maintenance, etc. OSU has an SPCC Plan (Spill Prevention, Control and Countermeasure Plan) in place due to the amount of fuels, gas and oil storage on campus.
3. Unused chemicals and other hazardous substances, such as strong acids and bases, paints, aerosol cans, etc. that are no longer needed, do not meet specifications, are contaminated, have exceeded their storage life, or are otherwise unusable;
4. Waste ethylene glycol and other coolants;
5. PCBs, batteries, lead paint and other miscellaneous materials including, contaminated rags and wipes, broken mercury-containing lamps (i.e. fluorescent lamps) and thermometers.

OSU EHS are available to assist Contractors with hazardous waste management procedures including disposal, although these activities remain the responsibility of the Contractor. The Contractor must promptly remove and dispose any regulated or hazardous waste generated by the Contractor (oil, paint, solvents, gasoline, etc.) from the site. OSU EHS must be contacted to sign off on all hazardous waste disposal paperwork to ensure proper disposal.

Solid Waste

Through daily activity, Contractors generate various types of solid waste. A solid waste is a solid, liquid, semi-solid or contained gaseous material, which is to be discarded or recycled, or has served its intended purposes.

All solid waste generated on an OSU work site (construction debris, boxes, pallets, etc.) must be removed and properly disposed or recycled in compliance with local, state, and federal regulations.

1. Contractors must supply their own waste or recycling collection containers, unless other means of disposal is agreed upon with the OSU Project Representative prior to the start of work.
2. The receptacle must be in good condition and labeled with the Contractor's name and the containers contents.
3. Waste collection containers must be located under a roofed structure or covered with a waterproof top when not in use (i.e. material not being placed into container, etc).

F. Directory of Service & Emergency Providers

Environmental Health and Safety

University Health Services Suite 002 / (405) 744-7241

University Health Services

1202 West Farm Road / (405) 744-7665

University Police Department

104 USDA Building / (405) 744-6523

Facilities Management

402 North Willis / (405) 744-7154

Stillwater, Oklahoma

Emergency - Ambulance, Fire, Police
(911)

Oklahoma State University Contractor Confined Space Entry Notification

When the contractor's work may involve entry into permit required confined spaces, Oklahoma State University must notify the contractor and inform them of the hazards associated with these spaces.

In the scope of this project, the workplace contains confined spaces and entry is allowed only through compliance with a confined space entry program. Prior to entry, the contractor must submit a copy of their confined space entry program to Environmental Health and Safety (EHS) and Facilities Management (FM).

Specific Location of the Permit Required Confined Space(s) e.g., building, street, cardinal direction, type of space, etc.: _____

Atmospheric Hazards (*existing or potential*):

- Oxygen (O₂) content less than 19.5% or greater than 23%
- LEL greater than 10%
- Hydrogen sulfide (H₂S)
- Carbon monoxide (CO)
- Other toxic gases or vapors
- Combustible dusts
- Work induced hazards, e.g., welding, hot work, painting, the use of chemicals, etc.

Health and Safety Hazards:

- Mechanical
- Electrical
- Engulfment
- Entrapment
- Slip / Trip / Fall
- Fire/Burn
- Heat Stress or Cold
- Other (specify)

Describe any precautions OSU will utilize to protect nearby OSU staff:

Will OSU personnel also be working in the confined space? Yes No

If "yes", a meeting to coordinate entry activities is required.

At the conclusion of the entry operations the contractor is required to discuss with the OSU representative the procedures followed and any hazards found or created during entry operations. Copies of permits used will be given to this representative and forwarded to EHS and FM.

OSU Representative (print and sign)

Contractor Representative (print and sign)

Contractor Company Name and Address: _____

Job or P.O. Number: _____

Date: _____